


RPZ 65mm -150mm Repair Kits

4A-200 RPZ APOLLO

4A-200 RPZ APOLLO

Size	65-80mm	100mm	150mm
RPZ Complete Rubber Repair Kit 7 (2), 8 (2), 15, 20, 22, 29, 31, 35, 37	4A00009	4A00A09	4A00C09
RPZ / DCV Check Rubber Repair Kit (single) 7, 8, 15	4A00001	4A00A01	4A00C01
RPZ 1st Check Module 5	4A00003	4A00A03	4A00C03
RPZ / DCV 2nd Check Module 14	4A00002	4A00A02	4A00C02
RPZ Relief Valve Rubber Kit 15, 20, 22, 29, 31, 35, 37	4A00C04	4A00C04	4A00C04
RPZ Relief Valve Complete Kit 15, 20, 21, 22, 23	4A00C05	4A00C05	4A00C05

1	Valve Body
2	Coupling
3	Cover
4	Test Cock, FxF
5	RP First Check Module
6	1st Check Retainer
7	Check Seat O-ring
8	Seat Disc
9	Disc Retainer
10	Washer
11	Handle (1st Chk Only)
12	Locknut
13	2nd Check Retainer
14	Second Check Module
15	O-ring, RV Port
16	Sensing Hose
17	Relief Valve Sub-Assy
18	Screw, 3/8-16 x .63" Lg
19	RV Body
20	Seat O-ring
21	Seat Cage
22	Bushing O-ring
23	RV Module
24	RV Clamp
25	RV Cover
26	Nipple, 1/2" Close
27	Screw, 5/16-18 x .50



28	RV Washer
29	RV Seat Disc
30	RV Stem
31	RV Stem O-ring
32	RV Bushing
33	RV Spring
34	Diaphragm Washer
35	Diaphragm
36	Diaphragm Plate
37	Dia. Plate O-ring
38	Screw, 5/16-18 x .75